



NOTES:

1. THE JOINT BOND ASSEMBLY (WHICH INCLUDES THE COPPER S-TRAP, NUT & BOLT, AND WELDED BOND TO THE PIPE) MUST BE COMPLETELY COATED WITH T.C. MASTIC PRIOR TO BEING INCASED IN CONCRETE.
2. TWO (2) NUTS ARE USED ON EACH CONNECTION TO MAINTAIN TORQUE ON CONNECTIONS.
3. WHEN THE FACTORY APPLIED COPPER TERMINAL STRAP IS NOT PRESENT, USE A CADWELD "PUNCH STRAP" NO. CAB496A36B0 WITH CADWALD MOLD NO. CAHAA-AF, AND SHOT NO. CA15XF-19.

NOT TO SCALE

	DRW: JAS	DATE: 4/12/16	JOINT BONDING	STANDARD PLATE NO. WATR-5004
	APP: CMD	DATE: 4/12/16		